

R8300 Office Docking

User Guide

R8300 – Office Docking

Product Overview

No.	Item
1	Undock Request Button
2	Release Button
3	Power LED
4	Docked LED
5	Alignment Posts
6	Latch
7	Docking Connector
8	USB Ports
9	Audio Out Jack
10	Microphone Input Jack
11	Keyboard / Mouse PS/2 Port
12	VGA Port
13	Ethernet Port
14	Serial Port 1 (COM1)
15	Serial Port 2 (COM2)
16	DC-IN Jack*
17	Kensington Lock Slot (dock only)



*Please contact dealer for appropriate adapter.

Docking the Laptop

1. Remove the protective rubber cover of the docking connector on the Laptop.



2. Align the Laptop by the alignment posts and docking connector and then place the Laptop onto the docking cradle.



3. Slightly press to secure the Laptop onto the docking cradle. The *Power* and *Docked* LED indicators will light on.



4. Open the lid of the Laptop. The Laptop is ready to use.



Undocking the Laptop

IMPORTANT: To avoid data loss, do not remove the Laptop when the *Docked* LED indicator is on.

1. Push the **Undock Request** button. The *Docked* LED indicator turns off.



2. Push the **Release** button.



3. Lift to remove the Laptop.